

SECTION THRU ABUTMENT Scale: 3/6" = 1'-0"

I. Stack bags as required. Joints between bags in successive rows and tiers shall be staggered.

2. Refer to General Plan for any

excavation requirements.
3. Place top bag flush with face of footing.

4. If on piles, place debonding material around piles with greater than 3'-0" exposure.

5. All bags' shall be Ift. max. thick, 3 ft. max. wide, and 4 ft. max. length.

6. Remove debris before installation of FHWA APPROVAL

DATE:

DATE: 11/6/96	
REVISIONS	
SHA	FHWA
8-5-08	

APPROVAL

E.S Freedown DIRECTOR OFFICE OF BRIDGE DEVEL STATE OF MARYLAND DEPARTMENT OF TRANSPORTATION STATE HIGHWAY ADMINISTRATION OFFICE OF BRIDGE DEVELOPMENT

GROUT BAG SECTION CASE WHERE SCOUR AND UNDERMINING HAS OCCURRED AT ABUTMENT

**STANDARD NO.** BR-SR(0.09)-96-316

SHEET  $\perp$  OF  $\frac{7}{}$ 

TRUCTURAL